

LHS-250

Elbow Exit Button

- Plastic with metal push plate
- Surface mount
- Legend: Exit
- Concealed fittings
- Change-over-contacts
- Status LED

H	W	D
250	95	23



DRB-ELB Series

Elbow Switch

- Plastic
- Surface mount
- Concealed fittings
- Change-over-contacts

H	W	D
250	95	23

DRB-ELB-01



DRB-ELB-02



DRB002-ND

Exit Button

- Brushed Stainless Steel
- All action button
- Surface mount
- Narrow style
- Legend: Push to open / wheelchair symbol
- COM / NO / NC
Change-over-contacts

H	W	D
114	43	43

